





COMBINATION DISCUS PADLOCK

SETTING UP YOUR OWN COMBINATION

①  With Factory Preset "0 0 0 0" Open the lock.	②  Turn the set button on the back 90° in the direction of the arrow.
③  Set dials to your desired combination, e.g. 1234. Note: Please turn the dials to the sunken line.	④  Turn back the set button to the original position in the direction of the arrow. Your combination is set!

1. Open the lock using the original combination (which is "0 0 0 0").
2. Slide the lock tab to the left to ensure the lock is open.
3. Rotate the lock to view the back.
4. Use a small flathead screwdriver or a coin to rotate the slotted screw on the back 90 degrees to change.
5. Set your desired new password on the dials while the screw is in the programming position.
6. Return the slotted screw to its original position to lock in the new combination.
7. Test the new combination: Scramble the dials, and then enter your new code and slide the tab to confirm it opens the lock.

IMPORTANT NOTE

Always remember your new combination, as resetting the lock without the correct code can be difficult.